


ADAPTADORES


ADAPTADOR MACHO NPT X FEMEA BSP (Adapters - Threads Reducer / expander)

MFS



Adaptador com ref. em Aço Carbono (S)

OBS: **MFS.....**
Quando rosca B
for menor que
Rosca A.




Ref.	Rosca A NPT	Rosca B BSP
MFS 1/8 NPT X 1/8 BSP	1/8	1/8
MFS 1/8 NPT X 1/4 BSP	1/8	1/4
MFS 1/8 NPT X 3/8 BSP	1/8	3/8
MFS 1/8 NPT X 1/2 BSP	1/8	1/2
MFS 1/4 NPT X 1/8 BSP	1/4	1/8
MFS 1/4 NPT X 1/4 BSP	1/4	1/4
MFS 1/4 NPT X 3/8 BSP	1/4	3/8
MFS 1/4 NPT X 1/2 BSP	1/4	1/2
MFS 1/4 NPT X 3/4 BSP	1/4	3/4
MFS 3/8 NPT X 1/8 BSP	3/8	1/8
MFS 3/8 NPT X 1/4 BSP	3/8	1/4
MFS 3/8 NPT X 3/8 BSP	3/8	3/8
MFS 3/8 NPT X 1/2 BSP	3/8	1/2
MFS 1/2 NPT X 1/8 BSP	1/2	1/8
MFS 1/2 NPT X 1/4 BSP	1/2	1/4
MFS 1/2 NPT X 3/8 BSP	1/2	3/8
MFS 1/2 NPT X 1/2 BSP	1/2	1/2
MFS 1/2 NPT X 3/4 BSP	1/2	3/4
MFS 1/2 NPT X 1 BSP	1/2	1
MFS 3/4 NPT X 1/4 BSP	3/4	1/4
MFS 3/4 NPT X 3/8 BSP	3/4	3/8
MFS 3/4 NPT X 1/2 BSP	3/4	1/2
MFS 3/4 NPT X 3/4 BSP	3/4	3/4
MFS 3/4 NPT X 1 BSP	3/4	1
MFS 1 NPT X 3/8 BSP	1	3/8
MFS 1 NPT X 1/2 BSP	1	1/2
MFS 1 NPT X 3/4 BSP	1	3/4
MFS 1 NPT X 1 BSP	1	1
MFS 1 NPT X 1.1/4 BSP	1	1.1/4
MFS 1.1/4 NPT X 1/2 BSP	1.1/4	1/2
MFS 1.1/4 NPT X 3/4 BSP	1.1/4	3/4
MFS 1.1/4 NPT X 1 BSP	1.1/4	1
MFS 1.1/2 NPT X 3/4 BSP	1.1/2	3/4
MFS 1.1/2 NPT X 1 BSP	1.1/2	1
MFS 1.1/2 NPT X 1.1/4 BSP	1.1/2	1.1/4
MFS 2 NPT X 1/2 BSP	2	1/2
MFS 2 NPT X 1.1/4 BSP	2	1.1/4

1 - Materiais dos Adaptadores:

Aço Inoxidável (SS) = MFSS 1/2 NPT X 1/2 BSP
Latão (B) = MFB 1/2 NPT X 1/2 BSP

2 - Se necessário ter o chanfro de 30° para montagem em porca giratória "NPSM" (Rosca Macho NPT), acrescentar "K" no final da ref.
Ex. **MFSS 1/2 NPT X 3/4 BSP K**



3 - Consulte para outras combinações de Rosca NPT X BSP.

4 - Fornecemos com Roscas de acordo com suas necessidades e combinações.